

IDD-213G User Manual

(Rev. 1.5)



Sinocastel Co., Ltd.

September, 2014

Contents



1. Introduction.....	3
2. Specifications.....	4
2.1 External Interface	4
2.2 Status Indicator	5
2.3 Technical Parameters	6
3. Device Configuration.....	8
3.1 PC Tool	8
3.2 SMS Instructions	8
4. Installation Instruction.....	10
4.1 SIM Card Installation.....	10
4.2 OBD Port.....	11
4.3 Device Installation	12
5. Functions	16
5.1 OBD Protocols	16
5.2 Location Inquiry	16
5.3 Regular GPS data reporting.....	16
5.4 Regular G-Sensor Data Reporting	17
5.5 Regular Diagnostic Data Reporting.....	17
5.6 DTCs Reporting	17
5.7 Cell ID Reporting	17
5.8 GPS Data Reporting in Sleep Mode	18
5.9 Data storage/Supplementary Report in Dead zones.....	18
5.10 Trip Mileage	18
5.11 Trip Fuel Consumption	18
5.12 Driving behavior monitoring.....	18
5.13 Alarms and Events Reporting.....	18
5.14 Working Mode.....	19
5.15 GPS/Cellular Timer.....	19
5.16 SMS Alert.....	19
5.17 Google Map Link.....	20
5.18 Remote Configuration	20
5.19 SMS Configuration	20
5.20 PC Tool Configuration.....	20
6. Disclaimer.....	21

7. Warranty	22
8. Statement.....	23

1. Introduction

IDD-213G is an intelligent on-board diagnostic device with OBD II and SAE J1939/J1708 (Heavy duty) compliant, it features plug-and-play technology, could read diagnostic info from vehicle ECU and capture location data with built-in GPS, then send them to backend server for real-time remote diagnostic and tracking purpose.

Packing List

Parts name		Quantity	Note
IDD-213G OBD Dongle		1	●
USB Configuration Cable		1	○
OBD II extension cable		1	○
9-Pin deutsch wiring harness		1	○
6-Pin deutsch Wiring harness		1	○
Power cable (including 3A Fuse)		1	○
SOS button		1	○

Note: ● Standard configuration ○ Optional configuration

(Optional accessories will not be included if there is no indication in the order)

2. Specifications

2.1 External Interface

Product appearance as follows:



1. Standard OBD Connector
Connect to the 16 pin on-board Diagnostic Link Connector (DLC).
2. Mini USB interface
Connect to PC through USB configuration cable.
3. SOS button Interface
This is a SOS button interface, to connect the SOS button for emergency, interface type is MMCX.
4. SIM Card slot

2.2 Status Indicator

Indicator	Color	Status
Power/OBD LED	Red	Blinking (on 0.5s, off 0.5s) - Trying to access OBD system or power off Solid on - Successful OBD communication Solid off - Tracker mode or in sleep
Cellular LED	Orange-red	Fast blinking (on 0.5s, off 0.5s) - No SIM card or network searching Slow blinking (on 0.5s, off 2.5s) - Registered network Solid on - Logged into the server Solid off - Cellular off
GPS LED	Green	Blinking (on 1s, off 1s) - GPS signal is good Solid on - Searching for GPS signal Solid off - GPS off
Buzzer	Beep	One beep - Power on Two beeps - Successful OBD communication Three beeps - Successful log in Four beeps - Trip end and stop OBD communication Five beeps - Power off Six beeps - Fail to access OBD system Five beeps (short beep) - Alarm indication

2.3 Technical Parameters

Mechanical	Dimension	63mm (L) x 48mm (W) x 28mm (H)
	Weight	50g
Interface		OBD interface: 16 pin standard OBD II Configuration interface: Mini USB SOS button interface: MMCX SIM card interface: Push-Push Type
Storage		2MB FLASH, can store up to 24000 GPS data
Data Transmission		GPRS/SMS
Positioning Mode		GPS/A-GPS
OBD Protocol		SAE J1850 PWM SAE J1850 VPW ISO 9141-2 ISO 14230-4 ISO 15765-4 SAE J1939 (Heavy duty) SAE J1587/J1708 (Heavy duty)
Power	Working Voltage	9-36VDC
	Working Current	Average Current: <150mA@13.8/27.6VDC Max. Current: <200mA@13.8/27.6VDC Sleep Current: <10mA@12/24VDC
	Internal Battery	3.7V/160mA Lithium battery
3-axis Accelerometer		+/-2g, +/-4g, +/-8g, +/-16g
GPS		Channels: 50 Sensitivity: -160dBm Accuracy: 5m CEP Cold start: <32s Warm start: <32s Hot start: <1s
Cellular		Frequency: Quad-band 850/900/1800/1900MHz Protocol: TCP/IP Sensitivity: -107dBm@850/900MHz -106dBm@1800/1900MHz Output Power: Class 4 (2W)@850/900MHz

		Class 1 (1W)@1800/1900MHz
LED Indicator		OBD/Cellular/GPS
Buzzer		System status/Alarm indication
Antenna	Cellular Antenna	Built-in
	GPS Antenna	Built-in
Certification		CE
		E-Mark (Pending)
Environment	Working Temperature	-30°C ~ +70°C
	Storage Temperature	-40°C ~ +85°C
	Humidity	5%~95% (no frog)

3. Device Configuration

3.1 PC Tool

Download USB driver and PC Tool at <http://www.sinocastel.com/en/Downloads/>.

Install the USB driver and PC Tool on your PC.

Connect device to PC through USB configuration cable, open the OBD PC Tool, click on "Help->User manual" for configuration reference.

3.2 SMS Instructions

SMS command is mainly for remote maintenance. The message content is text format. Default secret key is the last 6 digits of the device ID. The key can only be changed through PC Tool. SMS format is defined as follows:

3.2.1 Set IP parameters

Send SMS `*SecretKey#set gprs#APN,User>Password,IP,Port*`, device will reply `*set gprs#ok*` or `*set gprs#fail*`.

e.g.: `*123456#set gprs#cmnet,,113.98.241.66,11088*`

3.2.2 Read IP parameters

Send SMS `*SecretKey#get gprs#*`, device will reply `*get gprs#APN,User>Password,IP,Port*`.

e.g.: `*123456#get gprs#*`

3.2.3 Set domain parameters

Send SMS `*SecretKey#set domain #APN,User>Password,IP,Port*`, device will reply `*set domain#ok*` or `*set domain#fail*`.

e.g.: `*123456#set domain# cmnet,,obd.livetelematics.com,11088*`

3.2.4 Read domain parameters

Send SMS `*SecretKey#get domain#*`, device will reply `*get domain#APN,User>Password,domain,Port*`.

e.g.: `*123456#get domain#*`

3.2.5 Get current location

Send SMS *SecretKey#position#*, device will reply

position#[http://maps.google.com /?q=latitude,longitude](http://maps.google.com/?q=latitude,longitude).

e.g.: *123456#position#*<http://maps.google.com/?q=22.536934,114.021425>*

3.2.6 Set working mode

Send SMS *SecretKey #set workmode#mode*, device will reply

set workmode#ok/fail.

mode = passenger, heavyduty or tracker

e.g.: *123456#set workmode#tracker*

3.2.7 Read working mode

Send SMS *SecretKey #get workmode#*, device will reply *get workmode#mode*.

mode = passenger, heavyduty or tracker

e.g.: *123456#get workmode#*

4. Installation Instruction

4.1 SIM Card Installation

1. Remove the SIM card cover.



2. Insert the SIM card and press gently, a click will be heard upon successfully placing the SIM card in its place, please follow the insertion direction marked on the SIM card cover.



3. Put the SIM card cover back.





Note:

There is a backup battery in the device, please make sure all lights are off before inserting or removing SIM card.

4.2 OBD Port

In general, the OBD port is located in the driver or passenger cabin, from the edge of dashboard on driver side to the border of 300mm. It is easy to touch by sitting in the driver's seat; the preferred location is within the area from steering post to the vehicle centerline.



4.3 Device Installation

Before installing the device, please make sure device has been configured with necessary parameters including network parameters and working mode.

Park the car and make sure engine is off, align the OBD connector of the device with the engine diagnostic port and simply push in place, ensuring the device is secure. There comes one beep indicating device is power on.



If the OBD port cover can not be closed back after device plugged in, please use OBD extension cable and mount the device in proper place.




Some heavy duties may need 9-Pin or 6-Pin deutsch wiring harness.



For vehicles do not have an OBD port, please use power cable to connect vehicle battery and configure the device with tracker mode.

Start engine, then device starts OBD communication, acquiring GPS info and GPRS connection. Various status can be indicated by lights and beeps.



OBD communication: The OBD light change its status to solid on and comes 2 beeps with successful OBD communication.

GPS function: The GPS light becomes blinking indicates that device has got its location.

GPRS connection: The Cellular light change its status to slow blinking indicates registered network, becomes solid on and comes 3 beeps indicate logged into the server.

Note:

***Firmware below V2.2.2:** When working with passenger or heavy duty mode, if OBD light keeps blinking and comes 6 beeps it means that device is not compatible with the vehicle, please change working mode. If it does not work with both passenger and heavy duty modes please change to tracker mode. To change working mode: 1) Remove the device, configure with PC Tool and install again. Or, 2) Send SMS `*secretkey#set workmode#mode*`, `secretkey` is the last 6 digits of device ID

as default, **mode** can be **passenger** or **heavyduty** or **tracker**, device will reboot and work with configured working mode. SMS should be sent within 10 minutes after device plugged in, or it will go into sleep. With tracker mode, diagnostic functions are not provided, device simply gets power from OBD port. When plugged in there comes 6 beeps indicating it is working with tracker mode, if engine keeps off or idle state device will go into sleep after 3 minutes.


***Firmware V2.2.2 and above:** When device is the first time power on (plugged in), it will scan OBD protocol according to pre-configured working mode (ie, passenger car or heavy duty mode), the maximum scanning time can be up to 10 minutes, if no OBD protocol is detected during this period, device will auto change working mode to tracker mode, if OBD protocol is detected, device will keep its working mode. After auto scanning period device will not change working mode anymore even it is re-plugged, unless working mode is re-configured with PC Tool, via SMS, or from server. If tracker mode is pre-configured device will not scan OBD protocol and keep working with tracker mode unless working mode is re-configured. There comes 6 beeps indicating that device is working with tracker mode.

***If GPS does not work**, please use OBD extension cable and mount the device in a proper place to make sure GPS signal can be well received.

***If dashboard lights are abnormal after installation, please remove the device and contact Sinocastel technical team.**

Log into www.livetelematics.com to check real-time monitor and trip reports.

Login



Vehicle monitoring list



Vehicle real time location

	Status	Lic.#	Name	Received time	ACC
 	Online Positioned	216G004	216G测试4	2013-08-22 15:33:53	ON

Vehicle real time status

5. Functions

5.1 OBD Protocols

Device supports all legislated OBD II protocols, it is also SAE J1939 and SAE J1708 compliant.

- SAE J1850-PWM
- SAE J1850-VPW
- ISO 9141-2
- ISO 14230-4 (KWP2000)
- ISO 15765-4 (CAN)
- SAE J1939 (Heavy duty)
- SAE J1587/J1708 (Heavy duty)

5.2 Location Inquiry

Upon receiving location inquiry message from server or via SMS, device reports GPS data immediately.

5.3 Regular GPS data reporting

GPS data can be sampled by 3 means: by time interval, by distance or by heading change. They can be enabled or disabled separately, only sampled by time interval is enabled by default.

The sample rate for time interval can be 2-600s and default setting is 30s, for distance interval can be 50-5000m and default setting is 500m, for heading change can be 5-90° and default setting is 15°.

There can be single or several groups of GPS data in one GPS message, determined by groups of GPS data per message, device will not report GPS message until it has collected specified groups of GPS data. Groups of GPS data per message can be 1-30 and default setting is 1.

For example, sampled by time interval and sampled by distance are enabled, and the respective settings are 10s and 500m, groups of GPS data per message is 5. Assume that vehicle is running at speed of 72km/h (20m/s), then it takes 25s to run out of 500m, so GPS data are sampled at 10th, 20th, 25th, 30th, 40th second and reported at 40th second as 5 groups of GPS data have been collected at that time.

The suggested minimal interval for GPS report is 10s. For example, if only sampled by time interval is enabled, then the settings might be 10s of sample rate and 1 group of GPS data per message, or 5s of sample rate and 2 groups of GPS data per message.

5.4 Regular G-Sensor Data Reporting

Device reports G-Sensor data (g-value of X/Y/Z axis) according to configured time interval, this function is disabled by default.

The sample rate can be 200-6000ms and default setting is 1000ms.

There can be single or several groups of G-Sensor data in one G-Sensor message, determined by groups of G-Sensor data per message, device will not report G-Sensor message until it has collected specified groups of G-Sensor data. Groups of G-Sensor data per message can be 50-100 and default setting is 100.

5.5 Regular Diagnostic Data Reporting

Device is able to read variety of vehicle diagnostic data, also called PID (parameter ID), including vehicle speed, engine RPM, engine coolant temperature, mass flow air, etc, and report up to 10 types of PID data according to configured time interval.

The sample rate can be 2-600s and default setting is 60s.

There can be single or several groups of PID data in one PID message, determined by groups of PID data per message, device will not report PID message until it has collected specified groups of PID data. Groups of PID data per message can be 1-30 and default setting is 1.

The suggested minimal interval for PID report is 10s, for example, 10s of sample rate and 1 group of PID data per message, or 5s of sample rate and 2 groups of PID data per message.

5.6 DTCs Reporting

Device is able to read vehicle pending and stored DTCs (diagnostic trouble code), and freeze frame data. The backend server analyzes and displays the DTCs for users on time to avoid high repairing cost.

5.7 Cell ID Reporting

Device reports Cell ID every 30 seconds when it loses GPS signal, this function is disabled by default.

5.8 GPS Data Reporting in Sleep Mode

Device reports GPS data according to configured time interval during sleep. The time interval can be 10-1440min and default setting is 60min.

5.9 Data storage/Supplementary Report in Dead zones

When there is no cellular signal or cellular signal is poor, GPS and alarm information are stored, and reported after signal recovery. Supplementary report can be last for 15 minutes at most after ignition is off.

5.10 Trip Mileage

Device reports driving mileage in each reported message.

5.11 Trip Fuel Consumption

Device reports fuel consumption in each reported message.

5.12 Driving behavior monitoring

Real-time detects bad driving behavior, including Speeding, high RPM, hard acceleration, hard brake, excessive engine idle time.

5.13 Alarms and Events Reporting

Alarms and Events are reported when they are triggered or eliminated and there comes short beeps, beeps are disabled by default.

- Engine on/off ([Supported from firmware V2.1.2](#))
- High RPM (triggered and eliminated)
- Speeding (triggered and eliminated)
- Low battery voltage (triggered and eliminated)
- High engine coolant temperature (triggered and eliminated)
- Hard acceleration
- Hard brake
- Excessive engine idle time (triggered and eliminated)
- Fatigue driving (triggered and eliminated)
- Towed
- MIL on/off ([Supported from firmware V2.1.2](#))
- Excessive exhaust emission (triggered and eliminated)

- Plug indication
- Unplug notification
- Emergency

Default thresholds for alarms:

- High RPM: 4500r/min
- Speeding: 120km/h
- Low battery voltage: 10.5V
- High engine coolant temperature: 98°C
- Hard acceleration: 0.4g
- Hard brake: 0.6g
- Excessive engine idle time: 15min
- Fatigue driving: 240min

5.14 Working Mode

Device supports 3 types of working mode: Passenger car, Heavy duty and Tracker mode.

With tracker mode, device does not report diagnostic data, DTCs, trip fuel consumption and some alarms including high RPM, high engine coolant temperature, hard acceleration, hard brake, excessive engine idle time, MIL and excessive exhaust emission.

With Tracker mode, device wakes up from sleep on detecting motion state last for 20 seconds, and goes into sleep on detecting static state last for 3 minutes.

5.15 GPS/Cellular Timer

GPS and cellular can keep working after ignition off according to configured timer, but no regular reports during this period. This function is disabled by default. ([Supported from firmware V2.1.2](#))

The timer for GPS/GSM can be 5-7200min and default setting is 720min, for data connection can be 5-120min and default setting is 60min.

5.16 SMS Alert

If user mobile phone numbers are configured, device sends SMS to each user number when alarms are triggered or eliminated, it is disabled by default.

5.17 Google Map Link

Latitude and longitude in location SMS can be directly linked to Google map.

5.18 Remote Configuration

Users can configure device or update firmware through website:

<http://www.livetelematics.com>.

5.19 SMS Configuration

Users can configure device via SMS commands.

5.20 PC Tool Configuration

Users can configure device or update firmware through PC Tool.

6. Disclaimer

This user manual only applies to IDD-213G device.

The device is compatible with OBD II standard, it is also SAE J1939 and J1708 compliant. While some vehicles are not following those standards, therefore Sinocastel can not guarantee the OBD performance of the device with every vehicle.

The GPS function may be affected in electromagnetic shielding area or bunker place.

The device has a built-in cellular module. It should be used as far as possible away from fuel depots, chemical plants and other areas could cause an explosion. Most sensitive to external RF sites (such as gas stations, hospitals and school, etc.) may be equipped with radio frequency jamming equipment; some functions may be affected in the interference area.

As the device transmits data via cellular, please use the SIM card which supports data service and make sure that the account balances is sufficient. Do not use any SIM card which is restricted by region.

To make sure the products works well, please use the original accessories.

This manual is based on the "as-is" situation. Sinocastel will not guarantee the accuracy, reliability and content of the handbook. Also Sinocastel reserves the right to amend or withdrawn this manual without any prior notification.

7. Warranty

If product got quality problem within the warranty period, please bring the product together with a valid warranty card and purchase invoice to the dealer for checking. Please do not disassemble this product, this may result in damage, Sinocastel will not be responsible for those problem.

1 year of warranty since purchase time and life-long maintenance. For Failure or damage due to incorrect operation or not following the instruction, Sinocastel will provide paid maintenance within warranty period.

User name: _____

Contact number: _____

Address: _____

Post code: _____

Purchasing date: _____

Serial number: _____

Remark: _____

Please keep this card carefully in order to better serve you.

Distributor (Company Chop):

Maintenance Records

Product Model:

Date	Faults and maintenance of records		Maintenance (Signature)	User (Signature)
	Fault Description	Maintenance		

Note: This form must be carefully completed.

8. Statement

Without written permission from Sinocastel, it is prohibited reproduce, transmit, distribute or save part or all of the contents of this document in any form.

Sinocastel reserves the rights to modify or improve these products without any prior notification.

Sinocastel reserves the rights to change or cancel the content of this document without any prior notification.

All rights reserved by Sinocastel Co., Ltd.

Address: 5/F, 5th Building, Software Park, No. 2 Gaoxin C. 3rd Road, Nanshan,
Shenzhen, China

Postcode: 518057

Tel: (86)755-86156349

Fax: (86)755-86169366

<http://www.sinocastel.com>